
BRACKET MOVEMENT AND PRESET OPTIONS



A number of preset positions are set in the mechanism which are shown above with the corresponding letter on the remote control.

These positions can be changed apart from the IN and OUT.